

F150 21-25 TAILLIGHT EASY INSTALLATION

F150尾灯21-25安装说明



21-23 High LED Plug
24-25 High LED Plug
 21-23高配LED插头
 24-25高配LED插头



Plug in-dynamic
unplug-non-dynamic
 连接-有启动动画
 断开-无动画

- 1 Turn Signal+ [转向灯]
- 2 Brake Light+ [刹车]
- 3 Common Negative Pole [共负极]
- 4 Reverse Light+ [倒车灯]
- 5 Running Light+ [行车灯]



21-23 Low Profile Halogen Adapter
 21-23前期低配卤素不带雷达转接线



21-25 Halogen Adaptor Cable for Medium
 21-25中配卤素带雷达转接线



4. The original blind spot module.
 原车盲点模块



5. Insert the blind spot module connector and install.
 插入盲点模块连接器并安装



6. Press firmly to tighten the cover bracket and tighten the cover screws.
 压紧盖子支架, 并将盖子螺丝拧紧

HARNESS CONNECTION INSTRUCTIONS

线束安装说明

Our rear lamps do not include the blindspot module, You need to install the original blind spot module.
 我们的后灯不包括盲点模块, 您需要安装原车盲点模块。



1. Remove the 3 screws.
 移除3颗螺丝



2. Press firmly to open the cover.
 用力按压, 打开盖子



3. Find the radar plug.
 找到雷达插头

Model (车型)		Operation Mode (操作方式)
21-23 Low profile Halogen without Radar 21-23低配卤素不带雷达		 Please use the low profile adapter cable 请使用低配转接线
21-23 Medium Halogen with Radar 21-23中配卤素带雷达		 Please use the Medium adapter cable and install the blind spot module connector 请使用中配转接线并安装盲点模块连接器
21-23 Premium LED with Radar 21-23高配LED带雷达		PLUG&PLAY, and install the blind spot module connector 直接对插, 并安装盲点模块连接器
24-25 Medium Halogen with Radar 24-25中配卤素带雷达		 Please use the Medium adapter cable and install the blind spot module connector 请使用中配转接线并安装盲点模块连接器
24-25 Premium LED with Radar 24-25高配LED带雷达		PLUG&PLAY, and install the blind spot module connector 直接对插, 并安装盲点模块连接器